



MIC-KEY® ANVÄNDNING OCH SKÖTSEL I HEMMET

USE AND CARE OF MIC-KEY® GASTROSTOMY BUTTON IN THE HOME

1
This is what you do
Once a day:

1. Wash the skin around the stoma once a day as part of the daily morning or evening cleaning routine, then wipe the skin around the stoma dry.
2. Rinse the tubing with 10 – 20 ml water before and after each feeding.
3. Rotate Mic-Key® one turn in the stoma at the time of the daily morning or evening cleaning routine.

2
This is what you do
Once a week:

Check and replace the quantity of water in the balloon, for example every Monday.

3
This is what you do
Once every two months:

Regard and treat the Mic-Key® as an eating utensil. You should therefore replace the Mic-Key® about once every two months, by that time it will be discoloured and the anti-reflux valve will be weakened.